NAUTIZ X21

QUICK START GUIDE

handheld

① WHAT´S IN THE BOX

The pictures shown below may differ from the actual products.
To purchase additional or optional products, contact our customer center.

Nautiz X21 Main body

Standard battery

USB cable

② YOUR NAUTIZ X21

Front camera

Volume up

Volume down

Left scan trigger

Power button

Function key

Right scan trigger

handheld

② YOUR NAUTIZ X21

Flash LED

Microphone

Rear camera

Speaker

handheld

Barcode scanner window

Pogo Pin

USB type-C port

Handstrap

③ SIM/MICRO SD CARD

1. Pull out the nanoSIM / microSD card holder.

2. The card holder supports either two nanoSIM cards or one nanoSIM card and one microSD card.

3. Align the card holder with the slot and push it in completely. Ensure the cards remain flat as you slide the card holder back into place.

④ INSERT BATTERY

1. Insert the battery in the battery compartment, as shown in the image below.

2. Press and hold both plastic clips at the bottom, then push the battery towards the front.

3. Press down the battery to ensure it is securely locked in place.

⑤ REMOVE BATTERY

1. Press and hold both of the plastic clips at the bottom of the battery, as shown in the image below.

2. Push the battery towards the front and lift to remove it.

WARNING - There is a risk of fire and burns if the battery is handled improperly.
DO NOT disassemble, crush, puncture, short external contacts, or dispose of the battery pack in fire or water.
DO NOT attempt to open or service the battery.
Dispose of used batteries according to local recycling guidelines in your area.

CAUTION - To ensure the unit is working properly, please keep all connectors away from the contaminants such as dust, grease, mud, and water.
Negligence may cause the unit to lose communication, short circuit, or overheat.
If the connector is damaged, please ensure the connector is fully repaired before using the unit to avoid short-circuiting.

⑥ LED INDICATORS

LED	Description
Red	Battery charging
Green	Battery fully charged Barcode scanned successfully
Blue	Message

If the scanner app is running, the LED is controlled by the scanner app.
No LED will be lit when the battery is out even if an external power source
is connected.

⑦ CHARGING THE BATTERY

Before using your Nautiz X21 for the first time, you need to charge it.
Fully charged Nautiz X21 can take up to 4 hours. To charge your Nautiz X21,
please use the USB charging cable or the cradle. Connect the USB type-C
cable to the USB port on Nautiz X21 and the other end of the USB cable
connect to AC power Adapter into the electrical outlet on the USB plug. The
charging LED indicator on Nautiz X21 is turning red in the charging state.

Please go to www.handheldgroup.com/knowledgebase
to download more information.

handheld
www.handheldgroup.com