


# ALGIZ RT10

## QUICK START GUIDE




**handheld**

# ① WHAT'S IN THE BOX




ALGiZ R10 Main body




Standard battery

## ② YOUR ALGIZ RT10




### ③ YOUR ALGIZ RT10



## ④ SIM/MICRO SD CARD

This is how you insert and remove the Nano SIM/micro SD.



---


\* SIM 2 only available on RT10-RF1-AXX models

---

## ⑤ INSERT BATTERY

### To insert the battery


1. Insert the battery
2. Push the battery lock to the close position
3. Attach the battery cover
4. Insert and tighten battery cover screws



## ⑥ REMOVE BATTERY

### To remove the battery

1. Power off the device before removing the battery
2. Remove battery cover screws
3. Detach the battery cover
4. Push the battery lock to the open position
5. Remove the battery



Please go to [www.handheldgroup.com/knowledgebase](http://www.handheldgroup.com/knowledgebase) to download more information.

Version 1.1

**handheld**

[www.handheldgroup.com](http://www.handheldgroup.com)